

COMPATIBLE WITH
ARCS AND
LEADERS AND LORE EXPANSION

ARKS ORGANIZER



Missing or broken parts?
Email us at info@gamingtrunk.com
with a brief description and a few pictures.
We will be happy to help.

gamingtrunk.com



info@gamingtrunk.com



fb.com/GamingTrunk



CE UK CA 0-3 Age: 14+

WARNING:
CHOKING HAZARD—Small parts.
Not for children under 3 years.

Ne convient pas aux enfants de moins de
36 mois. Contient de petits éléments
pouvant être avalés. Risque d'étouffement.

© 2025 Gaming Trunk Inc.
43 Tamarack cir., Kemptville, ON
K0G1J0, Canada
www.gamingtrunk.com
info@gamingtrunk.com

SKU: ORG-ARC-01-FBA

Made in Canada

Assembly manual

Thank you for purchasing our Arks organizer for Arcs.
A digital copy of the manual is available for download on gamingtrunk.com

Tools required



The organizer assembly requires about 90 minutes.





The organizer is designed for no-glue assembly. However, applying some glue on the corner connections will increase trays durability. Due to variances in wood, a rubber mallet or glue may be required to secure the pieces together.

We recommend wood glue or another comparable quick setting, tacky glue.









Assembly tips:

- Use utility knife to cut parts out of the sheets. Panching parts may cause wood splitting.
- Some connections may feel too tight. Use of a rubber mallet is recommended to set the parts on their place.
- Due to the cutting process, some pieces may vary slightly. If the piece is symmetrical reversing it may help

Markers tray (Parts C; Sheets 2, 4)












Card tray (Parts A; Sheets 1-3)










Remove protective film from both sides of the tray lid


Dice and Tokens tray
(Parts D; Sheets 3, 5)



Player tray
(Parts B; Sheets 6-9)



4 Remove protective film from both sides of the tray lid



Plastic tray lid